

The science behind the report:

The six-core AMD Ryzen 5 PRO 5675U processor-based HP EliteBook 645 G9 achieved strong performance on industry-standard benchmarks

This document describes what we tested, how we tested, and what we found. To learn how these facts translate into real-world benefits, read the report The six-core AMD Ryzen 5 PRO 5675U processor-based HP EliteBook 645 G9 achieved strong performance on industry-standard benchmarks.

We concluded our hands-on testing on June 27, 2022. During testing, we determined the appropriate hardware and software configurations and applied updates as they became available. The results in this report reflect configurations that we finalized on April 26, 2022 or earlier. Unavoidably, these configurations may not represent the latest versions available when this report appears.

Our results

To learn more about how we have calculated the wins in this report, go to http://facts.pt/calculating-and-highlighting-wins. Unless we state otherwise, we have followed the rules and principles we outline in that document.

Table 1: Results of our performance testing.

	HP EliteBook 645 G9 AMD Ryzen™ 5 PRO 5675U	Dell™ Latitude™ 5420 Intel® Core™ i5-1145G7	HP EliteBook 645 G9 with AMD Ryzen5 PRO 5675U percentage advantage	
Cinebench R23 vR23.200 (Higher is better)	Cinebench R23 vR23.200 (Higher is better)			
Multi-core score	7,877	4,357	80.79	
Single-core score	1,407	1,390	1.22	
Geekbench 5 Pro (Higher is better)				
CPU multi-core score	5,837	4,817	21.18	
CPU single-core score	1,414	1,417	-0.21	
Passmark PerformanceTest10 (Higher is better)				
Overall Passmark Rating	4,607.7	3,106.0	48.35	
CPU Mark score	16,190.2	11,450.7	41.39	
2D Graphics Mark score	707.8	311.2	127.44	
3D Graphics Mark score	2,108.9	2,581.8	-18.32	
Memory Mark score	2,240.5	2,953.5	-24.14	
Disk Mark score	13,735.6	25,905.2	-46.98	



	HP EliteBook 645 G9 AMD Ryzen [™] 5 PRO 5675U	Dell™ Latitude™ 5420 Intel® Core™ i5-1145G7	HP EliteBook 645 G9 with AMD Ryzen5 PRO 5675U percentage advantage
PCMark 10 (Higher is better)			
Overall PCMark10 Rating	5,389	4,991	7.97
Essentials score	9,482	9,648	-1.72
Productivity score	8,628	6,560	31.52
Digital Content Creation score	5,192	5,333	-2.64
Procyon Photo Editing Benchmark (Higher is I	petter)	` 	`
Overall Procyon Photo Editing Rating	5,996	5,442	10.18
Word score	6,571	6,379	3.01
Excel score	5,855	5,104	14.71
PowerPoint score	5,846	5,212	12.16
Outlook score	5,513	4,915	12.17
Procyon Photo Editing Benchmark (Higher is I	petter)		
Overall Procyon Photo Editing Rating	6,559	5,451	20.33
Batch Processing score	6,771	5,321	27.25
Image Retouching score	6,354	5,586	13.75
Procyon Video Editing Benchmark (Higher is I	petter)		
Overall Procyon Video Editing Rating	1,646	1,415	16.33
Blender Benchmark 3.1.0 (Higher is better)	·	·	·
Monster (Samples per minute)	55.6	32.9	68.73
Junkshop (Samples per minute)	33.2	15.6	113.29
Classroom (Samples per minute	25.9	10.0	158.80

Table 2: Thermal results.

	HP EliteBook 645 G9 AMD Ryzen 5 PRO 5675U	Dell Latitude 5420 Intel Core i5-1145G7	HP EliteBook 645 G9 with AMD Ryzen5 PRO 5675U percentage advantage
Thermals while idle (Lower is better)			
Top hot spot idle (degrees Celsius)	42.7	48.9	14.52
Bottom hot spot idle (degrees Celsius)	47.8	52.7	10.25
Thermals while under CPU load - Cinebench R23 (Lower is better)			
Top hot spot idle (degrees Celsius)	31.3	33.9	8.31
Bottom hot spot idle (degrees Celsius)	32.1	34.6	7.79

Table 3: Acoustic results.

	HP EliteBook 645 G9 AMD Ryzen 5 PRO 5675U	Dell Latitude 5420 Intel Core i5-1145G7
Acoustics (lower is better)		
While idle (dB)	23.91	24.05
While under CPU load (running Cinebench R23) (dB)	27.05	26.95

System configuration information

Table 4: Detailed information on the systems we tested.

System configuration information	HP EliteBook 645 G9	Dell Latitude 5420
Processor		
Vendor	AMD	Intel
Model number	Ryzen 5 PRO 5675U	Core i5-1145G7
Core frequency (GHz)	2.3GHz – 4.3GHz	1.1GHz – 4.4GHz
Number of cores	6	4
Cache	16MB L3	8MB Intel Smart Cache
Memory		
Amount (GB)	16	16
Туре	DDR4 Dual Channel	DDR4 Dual Channel
Speed (MHz)	3,200	3,200
Integrated graphics		
Vendor	AMD	Intel
Model number	Radeon [™] Graphics	Iris® Xe Graphics
Storage	I	
Amount (GB)	512	512
Туре	NVMe® PCIe® Gen3	NVMe PCle Gen4
Connectivity/expansion		
Wired internet	1 x RJ-45 Ethernet Port	1 x RJ-45 Ethernet Port
Wireless internet	Realtek Wi-Fi 6 RTL8852BE	Intel Wi-Fi 6 AX201
Bluetooth	5.2	5.2
USB	3 x SuperSpeed USB Type-A 1 x SuperSpeed USB Type-C	1 x USB 3.2 Gen 1 1 x USB 3.2 Gen 1 with PowerShare
Thunderbolt	N/A	2 x Thunderbolt 4
Video	1 x HDMI 2.0	1 x HDMI 2.0

System configuration information	HP EliteBook 645 G9	Dell Latitude 5420	
Battery			
Туре	Lithium-ion	Lithium-ion	
Size	3-cell	4-cell	
Rated capacity (Wh)	51	63	
Display			
Size (in.)	15.6	14	
Туре	LED IPS UWVA Anti-Glare	LED Non-Touch Anti-Glare	
Resolution	1920x1080	1920x1080	
Touchscreen	Yes	No	
Operating system			
Vendor	Microsoft	Microsoft	
Name	Windows 11	Windows 11	
Build number or version	10.0.22000	10.0.22000	
BIOS			
BIOS name and version	HP U77 Ver. 01.05.00	Dell Inc. 1.15.1	
Dimensions			
Height (in)	0.78	0.76	
Width (in)	12.67	12.65	
Depth (in.)	8.42	8.35	
Weight (lb)	3.03	3.03	

How we tested

Setting up the systems

Creating and updating the OEM Windows 11 Pro Image

- 1. Boot the system.
- 2. Follow the on-screen instructions to complete installation, using the default selections when appropriate.
- 3. In the bottom right corner, click and adjust the Windows Power mode (plugged in) to Best Performance.
- 4. Unplug the system, and in the bottom right corner, click the battery icon. Adjust the Windows Power mode (on battery) to Best Performance, and plug the system back in.
- 5. Set DPI scaling to 100%, and set Screen and Sleep options to Never.
 - Right-click the desktop and select Display settings.
 - Under the Scale and layout section, for the Change the size of text, apps, and other items option, select 100%.
 - From the left column, select Power & Sleep.
 - For all power options listed under Screen and Sleep, select Never.
- 6. Disable User Account Control notifications.
 - Select Windows Start, type UAC, and press the Enter key.
 - Move the slider control to Never notify, and click OK.
- 7. Run Windows Update, and install all updates available.
- 8. Launch the Windows Store app, and install all Store app updates.
- 9. Launch each vendor's proprietary utility app installed on each system, and update any drivers or BIOS files.
 - For Dell, run the Dell Command Update utility.
 - For HP, run the HP Support Assistant utility.
 - To install the latest chipset and graphics drivers available, go to either https://www.intel.com/content/www/us/en/support.html or https://www.intel.com/content/www/us/en/support.html or https://www.intel.com/content/www/us/en/support.html or https://www.intel.com/content/www/us/en/support.html or https://www.amd.com/en/support.html or https://www.amd.com/en/support.
- 10. Verify the date and time are correct, and synchronize the system clock with the time server.
- 11. On the system with an Intel processor, install Intel CPU Runtime for OpenCL Applications for Windows OS (64bit or 32bit) from https://registrationcenter.intel.com/en/forms/?productid=3207&pass=yes.
- 12. On the system with an AMD processor, adjust the AMD Vari-Bright setting to Maximum brightness.
 - Right-click the desktop, and select AMD Radeon Software.
 - At the Welcome to the new Radeon Software experience, click Skip This.
 - In the top right corner, click the Settings Gear icon.
 - Click the Display tab.
 - Move the Vari-Bright slider to Maximum brightness.
- 13. Disable Automatic Windows Update.
 - Right-click the Windows Start button.
 - Select Computer Management.
 - Select Services and Applications.
 - Select Services.
 - Scroll down, and double-click Windows Update.
 - Click Stop.
 - From the Startup type drop-down menu, select Disabled.

Capturing an image

- 1. Connect an external HDD to the system.
- Right-click the desktop, and select Personalize→Home→Update & security→Backup→More options→See advanced settings→System Image Backup→Create a system image.
- 3. Verify that the external HDD is selected as the save drive, and click Next.
- 4. Verify that all drives are selected to back up, and click Next.
- 5. Click Start backup.
- 6. At Do you want to create a system repair disc, select No, and close the dialogs.

Restoring an image

- 1. Connect an external HDD to the system.
- 2. Press and hold the Shift key while Restarting the system.
- 3. Select Troubleshoot.
- 4. Select Advanced options.
- 5. Select See more recovery options.
- 6. Select System image recovery.
- 7. Select the User account.
- 8. Enter the system password, and click Continue.
- 9. Select Next at the Restore system files and settings screen.
- 10. Verify that the external HDD is selected, and click Next.
- 11. Once the recovery completes, click Finish.

Measuring performance

Testing with Cinebench R23

- 1. Download and install Cinebench R23 from the Microsoft Store.
- 2. Launch Cinebench.
- 3. Select either CPU (Multi Core) or CPU (Single Core), and click Start.
- 4. Record the result.
- 5. Wait 15 minutes before re-running.
- 6. Repeat steps 1 through 5 for a total of three runs for Single Core and three runs for Multi Core.

Testing with Geekbench 5

- 1. Download and install Geekbench 5 from https://www.geekbench.com/download/.
- 2. Launch Geekbench.
- 3. Click Run CPU Benchmark.
- 4. Record the result.
- 5. Wait 5 minutes before re-running.
- 6. Repeat steps 2 through 5 twice more.

Testing with PassMark PerformanceTest 10

- 1. Download and install with defaults PassMark PerformanceTest 10 from https://www.passmark.com/products/performancetest/download.php.
- 2. Launch PerformanceTest 10.
- 3. Click Run Benchmark on the main screen.
- 4. Click Yes to run all tests.
- 5. When the test completes, record the results.
- 6. Wait 5 minutes before re-running.
- 7. Repeat steps 2 through 6 twice more.

Testing with PCMark 10 Benchmark Test

Setting up the test

- 1. Purchase and download the PCMark 10 benchmark from https://benchmarks.ul.com/pcmark10.
- 2. Install PCMark 10.
- 3. Launch PCMark 10.
- 4. Select Business Edition, and input the license key.
- 5. Close PCMark 10.

Running the test

- 1. Boot the system.
- 2. Select Windows Start.
- 3. Type cmd, and press Ctrl+Shift+Enter.
- 4. Type Cmd.exe /c start /wait Rundll32.exe advapi32.dll,ProcessIdleTasks. Do not interact with the system until the command completes.
- 5. After the command completes, wait five minutes before running the test.
- 6. Launch PCMark 10.
- 7. While on the Home tab, to begin the test, click Run.
- 8. When the test completes, record the results, and shut down the system.
- 9. Repeat steps 1 through 8 twice more, and record the median results.

Testing with the UL Procyon benchmark suite

Setting up the test

- 1. Download and install UL Procyon.
- 2. Open UL Procyon.
- 3. Click on Office Productivity Benchmark.
- 4. Click Register.
- 5. Enter the license key for the Office Productivity Benchmark, and click Register.
- 6. Click Photo Editing Benchmark or Video Editing Benchmark.
- 7. Click Register.
- 8. Enter the license key for the Photo and Video Editing Benchmark, and click Register.
- 9. Before running the benchmarks, make sure to install licensed versions of Microsoft 365, Adobe® Photoshop® 22.0 or higher, Adobe Lightroom® Classic 10.0 or higher, and Adobe Premiere® 14.5 or higher.

Running the test

- 1. Boot the system.
- 2. Select Windows Start.
- 3. Type cmd, and press Ctrl+Shift+Enter.
- 4. Type Cmd.exe /c start /wait Rundll32.exe advapi32.dll,ProcessIdleTasks. Do not interact with the system until the command completes.
- 5. After the command completes, wait five minutes before running the test.
- 6. Launch UL Procyon.
- 7. Click Office Productivity Benchmark.
- 8. Click Run.
- 9. When the benchmark is complete, record the results.
- 10. Click Photo Editing Benchmark.
- 11. Click Run.
- 12. When the benchmark is complete, record the results.
- 13. Click Video Editing Benchmark.
- 14. Click Run.
- 15. When the benchmark is complete, record the results.
- 16. Shut down the system.
- 17. Repeat steps 1 through 16 twice more.

Blender Benchmark

We recorded how long it took to render various Blender workloads. We used Blender v3.1.0.

Setting up the test

- 1. Download and install Blender from https://www.blender.org/download/.
- 2. Download the following Blender workloads from https://www.blender.org/download/demo-files/.
 - Monster
 - Junkshop
 - Classroom
- 3. Launch Blender, and go to Edit \rightarrow Preferences \rightarrow System.
- 4. Select OptiX, and check the box next to the discrete graphics card option. If OptiX is not available, make sure the latest NVIDIA® graphics drivers are installed. If no dedicated graphics option is available, leave at default.
- 5. Close Blender.

Running the test

- 1. Launch Blender.
- 2. Click Open, and browse to the test workload.
- 3. Click the Render Properties tab.
- 4. Verify that the Render Engine is set to Cycles.
- 5. Verify that the Feature set is set to Experimental.
- 6. Verify that the Device is set to GPU Compute.
- 7. Click Render \rightarrow Render Image.
- 8. Record the elapsed time result.
- 9. Wait 5 minutes before performing the next run.
- 10. Repeat steps 1 through 9 two more times.

Measuring thermals and acoustics

Measuring thermals while idle

- 1. Place the system under test in a climate-controlled room.
- 2. Allow the system to sit idle for 30 minutes.
- 3. Take an image of the top and bottom of the notebook with the FLIR thermal imaging camera.
- 4. Record the result.
- 5. Repeat steps 1 through 4 two more times.

Measuring thermals while under CPU load

- 1. Place the system under test in a climate-controlled room.
- 2. Boot the system and install Cinebench R23.
- 3. Wait 5 minutes before running the test.
- 4. Launch Cinebench R23.
- 5. Set the minimum test duration in Cinebench R23 to 40 minutes.
- 6. Run the 40-minute test.
- 7. After 30 minutes, take an image of the top and bottom of the notebook with the FLIR thermal imaging camera.
- 8. Record the result.
- 9. Shut down the computer, and let it cool for an hour.
- 10. Repeat steps 1 through 9 two more times.

Measuring acoustics while idle

- 1. Place the system under test in a sound-proofed professional sound booth.
- 2. Set the Extech SDL600 Sound Level Meter/Datalogger on a tripod that is 2 feet in front of and 1 foot above the system.
- 3. Boot the system, and wait 5 minutes.
- 4. Start the Extech SDL600, and allow the system to sit idle for 30 minutes.
- 5. After 30 minutes, stop the Extech SDL600.
- 6. Copy the log file from the Extech SDL600 SD card.
- 7. Power the system off for 10 minutes.
- 8. Repeat steps 1 through 7 two more times.

Measuring acoustics while under CPU load

- 1. Place the system under test in a sound-proofed professional sound booth.
- 2. Set the Extech SDL600 Sound Level Meter/Datalogger on a tripod that is 2 feet in front of and 1 foot above the system.
- 3. Boot the system, and install Cinebench R23.
- 4. Wait 5 minutes before running the test.
- 5. Launch Cinebench R23.
- 6. Set the minimum test duration in Cinebench R23 to 40 minutes.
- 7. Run the 40-minute test.
- 8. Start the Extech SDL600.
- 9. After 30 minutes, stop the Extech SDL600.
- 10. Copy the log file from the Extech SDL600 SD card.
- 11. Shut down the computer, and let it cool for an hour.
- 12. Repeat steps 1 through 11 two more times.

This project was commissioned by AMD.





Principled Technologies is a registered trademark of Principled Technologies, Inc. All other product names are the trademarks of their respective owners.

DISCLAIMER OF WARRANTIES; LIMITATION OF LIABILITY:

Principled Technologies, Inc. has made reasonable efforts to ensure the accuracy and validity of its testing, however, Principled Technologies, Inc. specifically disclaims any warranty, expressed or implied, relating to the test results and analysis, their accuracy, completeness or quality, including any implied warranty of fitness for any particular purpose. All persons or entities relying on the results of any testing do so at their own risk, and agree that Principled Technologies, Inc., its employees and its subcontractors shall have no liability whatsoever from any claim of loss or damage on account of any alleged error or defect in any testing procedure or result.

In no event shall Principled Technologies, Inc. be liable for indirect, special, incidental, or consequential damages in connection with its testing, even if advised of the possibility of such damages. In no event shall Principled Technologies, Inc.'s liability, including for direct damages, exceed the amounts paid in connection with Principled Technologies, Inc.'s testing. Customer's sole and exclusive remedies are as set forth herein.